






SPARE PARTS LIST

Part No.	Parts Name	Qty	Part No.	Parts Name	Qty
1	Screw	4	24	Nut	1
2	Rear cover	1	25	Screw	1
3	Speed control switch	1	26	Transparent base	1
4	Switch	1	27	Adjusting depth teeth	1
5	Sheath	1	28	Screw	1
6	Cable	1	29	Gauge guide plate	1
7	Stator seat	1	30	Transparent chassis	4
8	Brush cover	1	31	Screw	1
9	Carbon brush	1	32	Screw	1
10	Brush holder	1	33	Screw	1
11	Tension spring	1	34	Distance circle	1
12	Stator	1	35	Binary aluminum	1
13	Windshield ring	1	36	Little Three Feet	1
14	Screw	2	37	Screw	1
15	627 bearing	1	38	Small fork piece	1
16	Gasket	1	39	Screw	1
17	Dust ring	1	40	Transparent flake	1
18	Armature	1	41	Screw	1
19	15 wildcards	1	42	Seven letter font	1
20	6002 bearing	1	43	Aircraft rack	1
21	Wave pad	1	44	M6 butterfly nut	1
22	Housing	1	45	Big wrench	1
23	Collet	1	46	Small wrench	1