

EXPLODED VIEW



SPARE PARTS LIST

P/N	PARTS NAME	Qty	P/N	PARTS NAME	Qty
1	Front Handle	1	14	Piston Pin	1
2	Top Cover Set	1	15	Starter Assy	1
3	Cylinder Top Cover	1	16	Ignition Assy	1
4	Air Filter Cover	1	17	Fly Wheel	1
5	Air Filte	1	18	Crankcase Assy	1
6	Cylinder	1	19	Circlip	2
7	Braking Assy	1	20	Oil Pump Pipe	1
8	Spark Plug	1	21	Oil Pump	1
9	Piston Ring	1	22	Clutch Wedge	1
10	Piston	1	23	Carburetor	1
11	Washer	2	24	Intake Elbow	1
12	Muffler	1	25	Rear Handle Assy	1
13	Crank Shaft	1	26		